

Sehestedt' Pre-Varnish, for interior and exterior use

The Pre-Varnish is a covering, white paint for wood surfaces. It is easy to apply and after 18 hours so hard that it can be sanded over. This pre-coat paint being relatively poor in oil needs a final coat of linseed oil varnish (Sehestedt' White Varnish). The Pre-Varnish can also be used as white base for oil glazes on interior wood.

Ingredients: linseed oil standoil, copal cooking, silicic dioxide, Dolomite rock meal, bentonite, titan dioxide, isoaliphate, pine oil and orange turpentine and a blend of the dry substances calcium, zirconium/manganese.

Exterior coating format:

1. Sehestedt's Primer Oil Preventing Mold and Blueing on dry, clean surface (wood moisture under 15%)
2. Fill holes and do fine spackling with Sehestedt's Varnish Filler
3. Apply a base coat of Pre-Varnish, in exterior areas mix 1:1 with White Varnish, 18 hours drying time
4. Sand
5. 1-2 thin coats of Sehestedt's White Varnish. Allow each coat to dry for at least 24 hours and sand between the coats.

Stir well all varnishes before using.

Turn opened containers upside down for storage. Transfer unused portion of product into smaller container .

Coverage: approx. 0.75/10m<sup>2</sup> for one undiluted coat.

For interior low impact surfaces a final coat of Sehestedt' Pre-Varnish can be applied to produce a matt finish. It will hold on most old coats having been well cleaned before painting.

---